








Metal Seal / Rubber Seal 3 Port Solenoid Valve


VQZ100/200/300

Solenoid Valve Variation





Manifold Options



Body Ported

Plug Lead Unit

3 Port Solenoid Valve Series VQZ100/200/300 Single Unit


VQZ100 / How to Order Valve 1-**C6**-PR VQZ 1 5 5 CE compliant Series 1 VQZ100 body width 10 mm Type of actuation Option N.C. (A) : None 1 F: With bracket 13 (P)(R) Body type cket Function Specifications DC Symbol Port size [2(A) port] (0.35 W Standard type C3 ø3.2 one-touch fitting (0.9 W) ø4 one-touch fitting K Note 1) High pressure type C4 C6 ø6 one-touch fitting R Note 1, 2) \bigcirc External pilot type M5 M5 thread (Replaceable type) (0.9 W) KR Note 1, 2) High pressure/External pilot type Note) For inch size one-touch fittings, refer to page 15 Note 1) Option Note 2) For details on external pilot type, refer to page 15. Manual override Non-locking B: Locking type - 1 push type (Tool required) Use standard (DC) specification for continuous duty. Coil voltage 5 24 VDC **Electrical entry** 12 VDC 6 L: L plug M: M plug MO: M plug G: Grommet LO: L plug (DC speciconnector connecto connector connector with lead fication) without with lead without wire connecto wire connector With light/ With light/ With light/ With light/ surge voltage surge voltage surge voltage surge voltage suppressor suppressor suppressor suppressor Note) Standard lead wire length: 300 mm

> Note) For one-touch fittings to be mouned on this valve and the silencer part no., refer to back page 4.




Body Ported Series VQZ100/200/300

VQZ200/300 / How to Order Valve



SMC

2



Valve construction	Metal seal	Rubber seal	VQZ100 (Poppet seal)					
Fluid		Air, Inert gas						
Max. operating pressure (MPa)	0.7 (High pressure type: 1.0)	0.7	0.7 (High pressure type: 1.0)					
Min. operating pressure (MPa)	0.1	0.15	0.15					
Ambient and fluid temperature (°C)	-10 to 50 (No freezing)							
Max. operating frequency (Hz)	20	5	20					
Pilot exhaust method	Individua	l exhaust	Common exhaust					
Lubrication		Not required						
Manual override	Push typ	e/Locking type (Tool r	equired)					
Shock/Vibration resistance (m/s ²) Note)		150/30						
Enclosure	Dust	-tight (DIN terminal: IP	65*)					

Specifications

.J Note) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energised and deenergised states every once for each condition. (Value in the initial state)

Vibration resistance: No malfunction occurred in one sweep test between 45 and 2000 Hz. Test was performed to axis and right angle directions of the main valve and armature when pilot signal is ON and OFF. (Value in the initial state)

Solenoid Specifications

Electrical entry			Grommet (G) L plug connector (L)	M plug connector (M) DIN terminal (Y)				
			G, L, M Y					
Coil rated voltage	1	DC DC	24, 12					
(V)		AC 50/60 Hz	100, 110,	200, 220 [*]				
Allowable voltage f	luctu	ation	±10% of rat	ed voltage*				
		Standard	0.35 (With light: 0.4 (DIN	terminal with light: 0.45)]				
Power consumption (W)	DC	High speed response, high pressure	0.9 (With light: 0.95 (DIN terminal with light: 1.0					
		100 V	-	0.78 (With light: 0.87)				
Apparent power	AC	110 V [115 V]	-	0.86 (With light: 0.87) [0.94 (With light: 1.07)]				
(VA)*	AC	200 V	-	1.15 (With light: 1.30)				
		220 V [230 V]	-	0.86 (With light: 0.89) [1.39 (With light: 1.60)]				
Surge voltage supp	oresso	or	Diode (DIN terminal, Varistor when non-polar types)					
Indicator light			LED (Neon light when AC with DIN terminal)					
* In common bet	ween 1	10 VAC and 115 VA	C, and between 220 VAC and 23	30 VAC.				

 \ast For 115 VAC and 230 VAC, the allowable voltage is –15% to +5% of rated voltage.

Optional Specifications

High speed response type
High pressure type (Metal seal type only)

External pilot type*

* For details on external pilot type, refer to page 15.

Flow Characteristics

	Valve				Flow characteristics							Response time (ms) Note 1)				
Series	construc-	Model		1→2 (P→A)		2→3 (A→R)		Standard:	High	High		Note 2) Weight		
	tion			C [dm3/(s•bar)]	b	Cv	C [dm3/(s•bar)]	b	Cv	0.35 W	speed: 0.9 W	pressure: 0.9 W	AC	(g)		
VQZ100	N.C. valve	Poppet	VQZ115	0.59	0.44	0.17	0.56	0.30	0.14	10 or less	—	13 or less	22 or less	24		
	N.C.	Metal seal	VQZ212	1.2	0.21	0.30	1.3	0.24	0.33	22 or less	14 or less	18 or less	34 or less			
VQZ200	valve	Rubber seal	VQZ232	1.6	0.33	0.39	1.7	0.37	0.45	22 or less	15 or less	20 or less	36 or less	57		
VQZZUU	N.O.	Metal seal	VQZ222	1.2	0.25	0.31	1.3	0.20	0.31	22 or less	14 or less	18 or less	34 or less] 5/		
	valve	Rubber seal	VQZ242	1.6	0.36	0.40	1.7	0.36	0.45	22 or less	15 or less	20 or less	36 or less	1		
	N.C.	Metal seal	VQZ312	2.7	0.18	0.62	2.4	0.28	0.56	22 or less	17 or less	22 or less	34 or less			
VQZ300	valve	Rubber seal	VQZ332	3.5	0.34	0.87	3.0	0.33	0.72	33 or less	25 or less	33 or less	57 or less	93		
VQ2300	N.O.	Metal seal	VQZ322	2.6	0.21	0.59	2.2	0.16	0.49	22 or less	17 or less	22 or less	34 or less	93		
	valve	Rubber seal	VQZ342	3.5	0.38	0.88	2.9	0.27	0.69	33 or less	25 or less	33 or less	57 or less			


Note 1) Based on JIS B 8375-1981 (Supply pressure: 0.5 MPa; with light/surge voltage suppressor: clean air)


Response time values will change depending on pressure and air quality. Note 2) Weight for threaded connection

Body Ported Series VQZ100/200/300

Construction

VQZ100 Poppet type







Component Parts

No.	Description	Material	Note									
1	Body	Resin										
2	Spool valve	Aluminum/HNBR										
3	Pilot valve assembly	—										
4	P, R port	Resin/Aluminum	VQZ100-12A (Standard type) VQZ100-12B (External pilot type)									


VQZ200/300


Metal seal type







Rubber seal type









Component Parts


No.	Description	Material	Note		
1	Body	Aluminum die-casted			
Spool, Sleeve		Stainless steel	Metal seal		
2	Spool valve	Aluminum/HNBR	Rubber seal		
3	Piston	Resin			
4	Pilot valve assembly	_			

Note) For "How to Order Pilot Valve Assembly", refer to page 16.

Dimensions: VQZ100

Single Unit


Grommet (G): VQZ115-□G□1-C3, C4, C6, M5-PR-Q




Note) For model no. of one-touch fittings for P and R port and silencer, refer to back page 4.

L plug connector (L): VQZ115-□L□1-C3, C4, C6, M5-PR-Q


M plug connector (M): VQZ115-DMD1-C3, C4, C6, M5-PR-Q






Body Ported Series VQZ100/200/300


Dimensions: VQZ200




L plug connector (L): VQZ2□2(R)-□L□1-C4, C6, M5-Q



M plug connector (M): VQZ2□2(R)-□M□1-C4, C6, M5




DIN terminal (Y): VQZ2 2(R)- Y - 1-C4, C6, M5-Q




Dimensions: VQZ300

Single Unit




SMC


L plug connector (L): VQZ3□2(R)-□L□1-C6, C8, C10, 02-Q



M plug connector (M): VQZ3 2(R)- M 1-C6, C8, C10, 02-Q




DIN terminal (Y): VQZ3 2(R)- Y 1-C6, C8, C10, 02-Q




Body Ported

Plug Lead Unit


3 Port Solenoid Valve Series VQZ100/200/300 Manifold Connector Kit






Body Ported Series VQZ100/200/300


Manifold Specifications





How to Order Manifold Assembly (Example)



Dimensions: VQZ100









Dimen	sions									F	ormula: I	_1 = 10.5	5n + 9.5	L2 = 10).5n + 22	2.5 n: S	tations (r	max. 20	stations)
L n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	30.5	41	51.5	62	72.5	83	93.5	104	114.5	125	135.5	146	156.5	167	177.5	188	198.5	209	219.5
L2	43.5	54	64.5	75	85.5	96	106.5	117	127.5	138	148.5	159	169.5	180	190.5	201	211.5	222	232.5
L3	75	75	87.5	100	112.5	125	137.5	137.5	150	162.5	175	187.5	200	200	212.5	225	237.5	250	262.5
L4	85.5	85.5	98	110.5	123	135.5	148	148	160.5	173	185.5	198	210.5	210.5	223	235.5	248	260.5	273

Body Ported Series VQZ100/200/300

Dimensions: VQZ200



Dimensions: VQZ300




Body Ported Series VQZ100/200/300

Manifold Options

Blanking plate assembly VVQZ100-10A-5 (For VQZ100) VVQZ200-10A-2 (For VQZ200) VVQZ300-10A-2 (For VQZ300)

It is mounted onto the manifold block in preparation for removing a valve for maintenance reasons or when planning to mount a spare valve, etc.

Colour: White



ð

6			(mm)
Model	Α	L	D
KQP-23-X19	16	31.5	3.2
KQP-04-X19	16	32	6
KQP-06-X19	18	35	8
KQP-08-X19	20.5	39	10
KQP-10-X19	22	43	12
	KQP-23-X19 KQP-04-X19 KQP-06-X19 KQP-08-X19	Model A KQP-23-X19 16 KQP-04-X19 16 KQP-06-X19 18	Model A L KQP-23-X19 16 31.5 KQP-04-X19 16 32 KQP-06-X19 18 35 KQP-08-X19 20.5 39

DIN rail AXT100-DR-

Blanking plug KQP-23-X19 KQP-04-X19 KQP-06-X19 KQP-08-X19

KQP-10-X19

As for \Box , enter the number from the DIN rail dimensions table. For L dimension, refer to the dimensions of each kit.

Each manifold can be mounted on a DIN rail.

Insert "D" at the end of the manifold part number. The DIN rail is approximately 30 mm longer than the length of manifold.


rensions table	$\begin{array}{c} \bullet \bullet$	2.5 99 99
L Dimension	1.25	


L = 12.5n + 10.5

No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L dimension	23	35.5	48	60.5	73	85.5	98	110.5	123	135.5	148	160.5	173	185.5	198	210.5	223	235.5	248	260.
No.	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Silencer (For manifold EXH port)

Silencer is installed in the manifold EXH port.





Dimensions									
Model	Silencer pa								
107400									

Model	Silencer part no.
VQZ100	AN110-01
VQZ200	AN110-01
VQZ300	AN200-02

For a silencer to be mounted on a single valve unit, refer to back page 4.




External Pilot Specification

The external pilot specification is used when the operating pressure is below the minimum operating pressure of 0.1 to 0.15 MPa or when valve is used for a vacuum application.

Order a valve by adding the external pilot specification [R] to the part number.





Pressure Specifications


S	eries	VQZ100 Note 2)	VQZ200/300
External pilot pressure range	Metal seal	—	0.1 to 0.7 MPa
	Rubber seal (VQZ100: poppet)	0.2 to 0.7 MPa	0.15 to 0.7 MPa
Operating press	sure range Note 1)	–100 kPa	to 0.7 MPa

Note 1) In the case of the high pressure type, upper limit of max. operating pressure and external pilot pressure range is 1 MPa.

Note 2) Pump down from 1(P) port when VQZ100 series vacuum type is specified. Apply pressure from 3(R) port to relieve vacuum pressure. Set the release pressure at 50% of external pilot pressure or less.

Inch-size One-touch Fittings and Option Thread

Inch size one-touch fittings and NPT, NPTF and G thread are available.



How to Order Manifold

(Suffix each symbol to the end of part number.)


VV3QZ22-05C-00T-Q

(1 (P), 3 (R) ports)						
-	Rc					
00N	NPT					
00T	NPTF					
00F	G					

IP65 Enclosure (Based on IEC529)

DIN terminal is available with IP65 enclosure.

How to Order Single Valve (Applicable to the VQZ200/300 rubber seal with the exception of the external pilot type)




Series VQZ Body Ported **Replacement Parts**

One-touch Fitting Assembly (For cylinder port)

Fitting size Model	C3	C4	C6	C8	C10	M5 (VQZ100 only)
VQZ100/200	VVQ1000-50A-C3	VVQ1000-50A-C4	VVQ1000-50A-C6	_	—	VVQ1000-50A-M5
VQZ300	_	_	VVQ1000-51A-C6	VVQ1000-51A-C8	VVQ1000-51A-C10	_

Note) Purchasing order is available in units of 10 pieces.


<Plug connector assembly>



Without lead wire: SY100-30-A (with connector and 2 sockets only)

Le	Lead wire length					
	-	300 mm				
	6	600 mm				
	10	1000 mm				
	15	1500 mm				
	20	2000 mm				
	25	2500 mm				
	30	3000 mm				
	50	5000 mm				

<Pilot valve assembly>



VQZ115□-□M□1

V111 M- L

-Gasket and screw assemblys

EX.) In case of 2000 mm of lead wire

VQZ115-5LO1-M5-PR-Q SY100-30-4A-20

How to Order

For DC

<gasket< th=""><th>t and scre</th><th>w assembly></th><th></th><th></th></gasket<>	t and scre	w assembly>		
	/	Part no.	<din (applicable="" 300)="" terminal="" the="" to="" type="" vqz200=""></din>	
VQZ10)0 V	/QZ100-GS-2		
VQZ20)0 V	/QZ200-GS-2	V115 - 5 Y - X110	
VQZ30)0 V	/QZ300-GS-2	Function •	
Note)	Each unit has o	hber consists of 10 units. one gasket and two using order is available in nes.	Symbol Specifications DC AC - Standard type (0.35 W) (0.35 W) B Note) High speed response type (0.9 W) (0.9 W) K Note) High pressure type (0.9 W) (0.9 W)	cal entry •
Bracke	et assemb	2 3 4 5 6	Coil voltage Symbol Electrical entry 100 VAC (50/60 Hz) Y DIN terminal 200 VAC (50/60 Hz) YO DIN terminal without connector 220 VAC (50/60 Hz) YO DIN terminal without connector 24 VDC YZ DIN terminal with light/surge voltage suppressor 12 VDC YOS Note) DIN terminal with surge voltage suppressor, without connector	Light/surge voltage suppressor None Yes (With light)
	Part no.	Tightening torque (N•m	Note) Note) For AC voltage valves there is no "S" option. It is already built-in to	the rectifier
VQZ100	VQZ100-FB	0.45 to 0.55	circuit.	
VQZ200	VQZ200-FB	0.25 to 0.35	🗥 Caution	
VQZ300	VQZ300-FB	0.25 to 0.35	When replacing the pilot valve assembly, use caution	
Note)	Tightening torq the valve.	ue when mounting a brack	is not possible to convert to a V115 (DIN terminal) from (grommet, L type, M type), or vice versa.	n a v111

Ŋ the valve.

Base Mounted

Plug Lead Unit

3 Port Solenoid Valve Series VQZ100/200/300 Single Unit

1-01-VQZ 1 5 5 1 CE compliant Series 1 VQZ100 body width 10 mm Type of actuation N.C. Port size [2(A) port] СР ZÞ TPA, 1 Without sub-plate 01 Rc 1/8 13 (P) (R Note) For optional thread type, (NPT, NPTF, G) refer to page 31. Body type 5 Base mounted Manual override B: Locking type Non-locking - : (Tool required) push type Function DC Symbol Specifications (0.35 W) Standard type (0.9 W) K Note 1) High pressure type R Note 1, 2) 0 External pilot type (0.9 W) KR Note 1, 2) High pressure/External pilot type Electrical entry Note 1) Option Note 2) For details on external pilot type, refer to page 31. G: Grommet L: L plug LO: L plug M: M plug MO: M plug (DC speciconnector connector connector connector fication) with lead without with lead without wire connector wire connector With light/ With light/ With light/ With light/ Caution surge voltage surge voltage surge voltage surge voltage suppressor suppressor suppressor suppressor Use standard (DC) specification for continuous duty. Note) Standard lead wire length: 300 mm


VQZ100 / How to Order Valve

Coil voltage

	ii venage	
5	24 VDC	Note) For sub-plate part no.
6	12 VDC	refer to page 32.

Base Mounted Series VQZ100/200/300

VQZ200/300 / How to Order Valve



1	100 VAC (50/60 Hz)	Note) For sub-plate part no.,
2	200 VAC (50/60 Hz)	refer to page 32.
3	110 VAC [115 VAC] (50/60 Hz)	
4	220 VAC [230 VAC] (50/60 Hz)	Note) Ac specification is only
5	24 VDC	with Y, YO, YZ type.
6	12 VDC	

to page 32.

pecification is only available , YO, YZ type.



Valve construction	Metal seal	Rubber seal	VQZ100 (Poppet seal			
Fluid	Air, Inert gas					
Max. operating pressure (MPa)	0.7 (High pressure type: 1.0) 0.7 0.7 (High pressure type:					
Min. operating pressure (MPa)	0.1	0.15	0.15			
Ambient and fluid temperature (°C)	-10 to 50 (No freezing)					
Max. operating frequency (Hz)	20	5	20			
Pilot exhaust method	Individual exhaust Common exhaust					
Lubrication		Not required				
Manual override	Push typ	be/Locking type (Tool i	required)			
Shock/Vibration resistance (m/s ²) Note	150/30					
Enclosure	Dust-tight (DIN terminal: IP65*)					

and at the right angles to the main valve and armature in both energised and deenergised states every once for each condition. (Value in the initial state)

Vibration resistance: No malfunction occurred in one sweep test between 45 and 2000 Hz. Test was performed to axis and right angle directions of the main valve and armature when pilot signal is ON and OFF. (Value in the initial state)

Solenoid Specifications

Specifications

Electrical entry			Grommet (G) M plug connector L plug connector (L) DIN terminal (Y)			
			G, L, M	Y		
Coil rated voltage	1	00	24,	12		
(V)		AC 50/60 Hz	100, 110,	200, 220*		
Allowable voltage fluctuation			±10% of rat	ed voltage*		
		Standard	0.35 (With light: 0.4 (DIN	terminal with light: 0.45)]		
Power consumption (W)	DC	High speed response, high pressure	0.9 (With light: 0.95 (DIN terminal with light:			
	AC	100 V	-	0.78 (With light: 0.87)		
Apparent power		110 V [115 V]	-	0.86 (With light: 0.87) [0.94 (With light: 1.07)]		
(VA)		200 V	-	1.15 (With light: 1.30)		
	220 V [230 V]		- 0.86 (With light: 0. - [1.39 (With light: 1.			
Surge voltage suppressor			Diode (DIN terminal, Varistor when non-polar types)			
Indicator light			LED (Neon light when AC with DIN terminal)			
		40.1/0.0		22140		

 \ast In common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC. \ast For 115 VAC and 230 VAC, the allowable voltage is –15% to +5% of rated voltage.))

Flow Characteristics

	Valve	Velue			Flow characteristics					Response time (ms) Note 1)				Note 2)
Series	construc-	Mode	el	1→2 (P→A) 2→3		2→3 ((A→R)		Standard:	High	High		Weight
tion	tion			C [dm3/(s•bar)]	b	Cv	C [dm3/(s•bar)]	b	Cv	0.35 W 0.9 W		pressure: 0.9 W	AC	(g)
VQZ100	N.C. valve	Poppet	VQZ115	0.87	0.46	0.23	1.0	0.35	0.25	10 or less	—	13 or less	22 or less	24
	N.C. valve N.O. valve	Metal seal	VQZ215	1.7	0.17	0.38	2.0	0.20	0.45	22 or less	14 or less	18 or less	34 or less	
VQZ200		Rubber seal	VQZ235	2.3	0.46	0.65	3.0	0.40	0.80	22 or less	15 or less	20 or less	36 or less	52
VQZZUU		Metal seal	VQZ225	1.7	0.18	0.38	1.8	0.21	0.39	22 or less	14 or less	18 or less	34 or less	
		Rubber seal	VQZ245	2.5	0.43	0.67	3.0	0.30	0.74	22 or less	15 or less	20 or less	36 or less	
	N.C.	Metal seal	VQZ315	3.0	0.21	0.70	3.2	0.27	0.80	22 or less	17 or less	22 or less	34 or less	
V07200	valve	Rubber seal	VQZ335	4.5	0.42	1.3	4.1	0.36	1.0	33 or less	25 or less	33 or less	57 or less	78
VQZ300	N.O.	Metal seal	VQZ325	2.9	0.21	0.72	2.9	0.16	0.69	22 or less	17 or less	22 or less	34 or less	
	valve	Rubber seal	VQZ345	4.4	0.45	1.2	4.5	0.38	1.2	33 or less	25 or less	33 or less	57 or less	

Note 1) Based on JIS B 8375-1981 (Supply pressure: 0.5 MPa; with light/surge voltage suppressor: clean air) Response time values will change depending on pressure and air quality.


Note 2) Weight without sub-plate.

Base Mounted Series VQZ100/200/300


Dimensions: VQZ100

Single Unit


Grommet (G): VQZ115(R)-□G□1-01-Q



L plug connector (L): VQZ115(R)-□L□1-01-Q




M plug connector (M): VQZ115(R)-□M□1-01-Q




Dimensions: VQZ200

Single Unit


Grommet (G): VQZ2 5(R)- G - 1-02 - Q




L plug connector (L): VQZ2 5(R)- L 1-02 -Q



M plug connector (M): VQZ2 5(R)- M - 1-02 -Q




DIN terminal (Y): VQZ2 5(R)- Y 1-01 -Q




Dimensions: VQZ300


Single Unit




L plug connector (L): VQZ3 5(R)-L 1-03-Q



M plug connector (M): VQZ3□5(R)-□M□1-⁰²₀₃-Q



DIN terminal (Y): VQZ3 5(R)- Y - 1-02 -Q




Base Mounted

Plug Lead Unit


3 Port Solenoid Valve Series VQZ100/200/300 Manifold Connector Kit (E

VQZ100 / How to Order Manifold




Base Mounted Series VQZ100/200/300

VQZ200/300 / How to Order Manifold








		Piping specifications			Applicable	Appliaghla	Note) Manifold
Series	Base model	Port		Port size	solenoid	Applicable station	base
		location	1(P), 3(R)	2(A)	valve		weight (g)
VQZ100	VV3QZ15-□□C-□-Q	Side/Top	Rc 1/8	C3 (For ø3.2) C4 (For ø4) C6 (For ø6) M5 (M5 thread)	VQZ115	2 to 20 stations	2 stations: 83 Addition per station: 19
VQZ200	VV3QZ25-□□C-□-Q	Side	Rc 1/4	C4 (For ø4) C6 (For ø6) C8 (For ø8) Rc 1/8	VQZ2⊡5	2 to 20 stations	2 stations: 126 Addition per station: 38
VQZ300	VV3QZ35-□□C-□-Q	Side	1(P) port Rc 3/8 3(R) port Rc 1/4	C6 (For ø6) C8 (For ø8) C10 (For ø10) Rc 1/4	VQZ3⊡5	2 to 20 stations	2 stations: 209 Addition per station: 60
) Weight for threaded co	nnection.	•	·		<u>.</u>	

Optional Specifications

High speed response type
High pressure type (Metal seal type only)
External pilot type*

* For details on external pilot type, refer to page 31.


How to Order Manifold Assembly (Example)




Base Mounted Series VQZ100/200/300

Construction


VQZ100 Poppet type





Note) For "How to Order Pilot Valve Assembly", refer to page 32.

Dimensions: VQZ100



Dimer	Dimensions Formula: L1 = 10.5n + 9.5 L2 = 10.5n + 22.5 n: Stations (max. 20 stations)									stations)									
L n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	30.5	41	51.5	62	72.5	83	93.5	104	114.5	125	135.5	146	156.5	167	177.5	188	198.5	209	219.5
L2	43.5	54	64.5	75	85.5	96	106.5	117	127.5	138	148.5	159	169.5	180	190.5	201	211.5	222	232.5
L3	75	75	87.5	100	112.5	125	137.5	137.5	150	162.5	175	187.5	200	200	212.5	225	237.5	250	262.5
L4	85.5	85.5	98	110.5	123	135.5	148	148	160.5	173	185.5	198	210.5	210.5	223	235.5	248	260.5	273

54.7

¢

0

SMC


44.9

0

O.


Base Mounted Series VQZ100/200/300

Dimensions: VQZ200





Dimensions: VQZ300







Base Mounted Series VQZ100/200/300

Manifold Options

Blanking plate assembly VVQZ100-10A-5 (For VQZ100) VVQZ200-10A-5 (For VQZ200) VVQZ300-10A-5 (For VQZ300) It is mounted on to the manifold block in preparation for removing a valve for maintenance reasons or when planning to mount a spare valve, etc. **Blanking plug KQP-23-X19** Dimensions (mm) KQP-04-X19 Applicable D Model Α L **KQP-06-X19** fittings size ød 3.2 KQP-23-X19 16 31.5 3.2 **KQP-08-X19** ð 4 **KQP-04-X19** 16 32 6 KQP-10-X19 KQP-06-X19 6 18 35 8 KQP-08-X19 20.5 8 39 10 Colour: White 10 **KQP-10-X19** 22 43 12 L **DIN** rail 12.5 (Pitch) 5.25 7.5 AXT100-DR-As for \Box , enter the number from the DIN rail dimensions table. For L dimension, refer to the dimensions of each kit 5.5 Each manifold can be mounted on a DIN rail. 12.5 Insert "D" at the end of the manifold part number. L Dimension L = 12.5n + 10.5The DIN rail is approximately 30 mm longer than 9 10 11 12 13 14 15 16 17 18 19 20 No. 1 2 3 4 5 6 7 8 the length of manifold. L dimension 23 35.5 48 60.5 73 85.5 98 1105 123 135.5 148 160.5 173 185.5 198 210.5 223 235.5 248 260.5 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 21 22 No L dimension 273 285.5 298 310.5 323 335.5 348 360.5 373 385.5 398 410.5 423 435.5 448 460.5 473 485.5 498 510.5 Silencer (For manifold EXH port) 63 Silencer is installed in the manifold EXH port.





Dimens	Dimensions					
Model	Silencer part no.					
VQZ100	AN110-01					
VQZ200	AN200-02					
VQZ300	AN200-02					

Port plug VVQZ100-CP (For VQZ100)

This is used when changing piping location. (Side or Top) $\label{eq:constraint}$






External Pilot Specification

The external pilot specification is used when the operating pressure is below the minimum operating pressure of 0.1 to 0.15 MPa or when valve is used for a vacuum application.

Order a valve by adding the external pilot specification $\left[R\right]$ to the part number.



Pressure Specifications

S	Series	VQZ100 Note 2)	VQZ200/300			
Note 1)	Metal seal	—	0.1 to 0.7 MPa			
External pilot pressure range	Rubber seal (VQZ100: poppet)	0.2 to 0.7 MPa	0.15 to 0.7 MPa			
Operating press	sure range Note 1)	–100 kPa	to 0.7 MPa			

Note 1) In the case of the high pressure type, upper limit of max. operating pressure and external pilot pressure range is 1 MPa.

Note 2) When using the VQZ100 series for a vacuum application, vacuum air through its 1(P) port. When supplying vacuum-release air, supply it through its 3(R) port. But do not supply vacuum-release air exceeding 50% for the external pilot pressure.

Inch-size One-touch Fittings and Option Thread


Inch size one-touch fittings and NPT, NPTF and G thread are available.

					1	(C		de		t and orts)	
							-		Rc		
						I	N		NPT		
							T F	١	IPTF		
										_	
-	der po i nbol	't N1	N3	N7	N9	N11	NM No	ite 1)	M5	01	02
Syn	nbol le tubing		N3 ø5/32"	N7 ø1/4"	N9 ø5/16"	N11 ø3/8"	NM ^{No} Mixe		M5	01 1/8 thread	1/4
Syn Applicab	nbol le tubing	N1 ø1/8"							M5	1/8	1/4
Syn Applicab	nbol le tubing (Inch)	N1 ø1/8"							M5	1/8	02 1/4 threa

International Thread Standards Other than Rc

Rc specifications are standard for all ports, however, NPT, NPTF and G are available for international markets.

Add the appropriate symbol following the port size in the standard part number.




-	Rc
Ν	NPT
Т	NPTF
F	G

IP65 Enclosure (Based on IEC529)

DIN terminal is available with IP65 enclosure.

How to Order Single Valve (Applicable to the VQZ200/300 rubber seal with the



Series VQZ Base Mounted **Replacement Parts**

One-touch Fitting Assembly (For cylinder port)

Fitting size Model	C3	C4	C6	C8	C10	M5 (VQZ100 only)
VQZ100	VVQ1000-50A-C3	VVQ1000-50A-C4	VVQ1000-50A-C6	—	—	VVQ1000-50A-M5
VQZ200	—	VVQ1000-51A-C4	VVQ1000-51A-C6	VVQ1000-51A-C8	—	—
VQZ300	—	_	VVQ2000-51A-C6	VVQ2000-51A-C8	VVQ2000-51A-C10	—

Note) Purchasing order is available in units of 10 pieces.

<Plug connector assembly>

For DC: SY100-30-4A-

Without lead wire: SY100-30-A (with connector and 2 sockets only)

Le	Lead wire length						
	-	300 mm					
	6	600 mm					
	10	1000 mm					
	15	1500 mm					
	20	2000 mm					
	25	2500 mm					
	30	3000 mm					
	50	5000 mm					

<Pilot valve assembly> 5 V111 G Function Manual override Symbol Specifications DC AC (Applicable to VQZ100) 0.35 V Standard type \bigcirc Non-locking push type High speed response в Locking slotted type B Note) (0.9 W) type (Applicable to VQZ200, 300) Coil voltage High pressure type (0.9 W) 5 24 VDC K Note) (Metal seal type, 12 VDC 6 Poppet seal type) Note) Option With/Without manual override None (Applicable to VQZ200, 300) Yes (Applicable to VQZ100) М Electrical entry Symbol Light/surge voltage Electrical entry DC suppressor G Grommet (DC specification) None

Valve model no.

VQZ115
L
1

VQZ115□-□M□1

L plug connector with lead wire

M plug connector with lead wire

from that of the main valve model number.

L plug connector without connector

M plug connector without connector

Note) The electrical entry (L, M) for the VQZ100 pilot valve is different

Pilot valve model no.

V111 M- L

Yes

LU

LOU

MU

MOU

How to Order

Include the connector assembly part number together with the part number for the plug connector's solenoid valve without connector.


EX.) In case of 2000 mm of lead wire

For DC

VQZ115-5LO1-M5-Q SY100-30-4A-20

<Gasket and screw assembly>

and internal pilot type are common.



Series VQZ Safety Instructions

These safety instructions are intended to prevent a hazardous situation and/or equipment damage. These instructions indicate the level of potential hazard by labels of **"Caution"**, **"Warning"** or **"Danger"**. To ensure safety, be sure to observe ISO 4414 ^{Note 1}, JIS B 8370 ^{Note 2}) and other safety practices.

Explanation of the Labels

Labels	Explanation of the labels
\land Danger	In extreme conditions, there is a possible result of serious injury or loss of life.
A Warning	Operator error could result in serious injury or loss of life.
A Caution	Operator error could result in injury Note 3) or equipment damage. Note 4)

Note 1) ISO 4414: Pneumatic fluid power - General rules relating to systems

Note 2) JIS B 8370: General Rules for Pneumatic Equipment

Note 3) Injury indicates light wounds, burns and electrical shocks that do not require hospitalisation or hospital visits for long-term medical treatment.

Note 4) Equipment damage refers to extensive damage to the equipment and surrounding devices.

Selection/Handling/Applications

1. The compatibility of the pneumatic equipment is the responsibility of the person who designs the pneumatic system or decides its specifications.

Since the products specified here are used in various operating conditions, their compatibility for the specific pneumatic system must be based on specifications or post analysis and/or tests to meet the specific requirements. The expected performance and safety assurance are the responsibility of the person who has determined the compatibility of the system. This person should continuously review the suitability of all items specified, referring to the latest catalogue information with a view to giving due consideration to any possibility of equipment failure when configuring a system.

- 2. Only trained personnel should operate pneumatically operated machinery and equipment. Compressed air can be dangerous if handled incorrectly. Assembly, handling or repair of the systems using pneumatic equipment should be performed by trained and experienced operators. (Understanding JIS B 8370 General Rules for Pneumatic Equipment, and other safety rules are included.)
- 3. Do not service machinery/equipment or attempt to remove components until safety is confirmed.
 - 1. Inspection and maintenance of machinery/equipment should only be performed once measures to prevent falling or runaway of the driven objects have been confirmed.
 - When equipment is removed, confirm the safety process as mentioned above. Turn off the supply pressure for this equipment and exhaust all residual compressed air in the system, and release all the energy (liquid pressure, spring, condenser, gravity).
 Before machinery/equipment is restarted, take measures to prevent quick extension of a cylinder piston rod, etc.
- 4. Contact SMC if the product will be used in any of the following conditions:
 - 1. Conditions and environments beyond the given specifications, or if product is used outdoors.
 - Installation on equipment in conjunction with atomic energy, railway, air navigation, vehicles, medical equipment, food and beverages, recreation equipment, emergency stop circuits, clutch and brake circuits in press applications, or safety equipment.
 An application which has the possibility of having negative effects on people, property, requiring special safety analysis.
 - An application which has the possibility of having negative enects on people, property, requiring special safety analysis.
 If the products are used in an interlock circuit, prepare a double interlock style circuit with a mechanical protection function for the prevention of a breakdown. And, examine the devices periodically if they function normally or not.

■ Exemption from Liability

- 1. SMC, its officers and employees shall be exempted from liability for any loss or damage arising out of earthquakes or fire, action by a third person, accidents, customer error with or without intention, product misuse, and any other damages caused by abnormal operating conditions.
- 2. SMC, its officers and employees shall be exempted from liability for any direct or indirect loss or damage, including consequential loss or damage, loss of profits, or loss of chance, claims, demands, proceedings, costs, expenses, awards, judgments and any other liability whatsoever including legal costs and expenses, which may be suffered or incurred, whether in tort (including negligence), contract, breach of statutory duty, equity or otherwise.
- 3. SMC is exempted from liability for any damages caused by operations not contained in the catalogues and/or instruction manuals, and operations outside of the specification range.
- 4. SMC is exempted from liability for any loss or damage whatsoever caused by malfunctions of its products when combined with other devices or software.



Be sure to read this before handling.

For Safety Instructions and 3 Port Solenoid Valve Precautions, refer to "Precautions for Handling Pneumatic Devices" (M-03-E3A).


Manual Override Operation

ACaution

Without an electric signal for the solenoid valve the manual override is used for switching the main valve. Push type is standard. Locking type (Tool required) is available as an option.


1. For VQZ100

Push type



Press in the direction of the arrow


Locking type (Tool required)



Turn 90° in the direction of the arrow.


2. For VQZ200, 300

Push type (Tool required)



Push down on the manual override button with a small screwdriver until it stops. Release the screwdriver and the manual override will return.

Locking type (Tool required)



Push down completely on the manual override button with a small screwdriver. While down, turn clockwise 90° to lock it. Turn it counterclockwise to release it.

Locked position



Precautions

When operating with a screwdriver, turn it gently using a watch-maker's screwdriver. (Torque: less than 0.1 $N{\mbox{-}m})$


Press and rotate to lock the manual operation of VQZ200, and VQZ300. If rotated without pressing, breakage and air leakage could occur.

How to Use L/M Plug Connector

ACaution

1. Attaching and detaching connectors

To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve. To detach a connector remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.




Light/surge Voltage Suppressor

ACaution

1. L and M plug connector


<For DC>



2. DIN terminal

<For DC>


With light/surge voltage suppressor (YS, YOS)



Light/surge voltage suppressor (YZ)

NO.1 (-) (+) Coil NO.2 (+) (-) O Varistor

<For AC> With light (YZ)



Note) The varistor of the surge voltage suppressor has a residual voltage corresponding to the protective element and rated voltage; therefore, protect the controller side from the surge.





Be sure to read this before handling.


For Safety Instructions and 3 Port Solenoid Valve Precautions, refer to "Precautions for Handling Pneumatic Devices" (M-03-E3A).

Light/surge Voltage Suppressor

A Caution

1. Surge voltage countermeasures

When shutting off the DC power supply using an emergency circuit breaker, the valve may operate incorrectly due to surge voltage generated by other electric parts (e.g., the solenoid). To ensure that surge does not affect the valve, take anti-surge measures (diode for surge protection, etc.) or use a valve with diode to prevent reverse current. (For the model number, consult with SMC.)




 (1), (3): Examples of anti-surge measures
 (2) : Valve equipped with diode to prevent reverse current

Connection of Lead Wire

ACaution

1. Crimping of lead wires and sockets

Not necessary if ordering the with a pre-connected lead wire model. Strip 3.2 to 3.7 mm at the end of the lead wires, insert the ends of the core wires evenly into the sockets, and then crimp with a crimping tool. When this is done, take care that the coverings of the lead wires do not enter the core wire crimping area.



Crimping tool, Part no. DXT170-75-1

Connection of Lead Wire

ACaution


2. Attaching and detaching sockets with lead wires

Attaching

Insert the sockets into the square holes of the connector (\oplus , \ominus indication), and continue to push the sockets all the way in until they lock by hooking into the seats in the connector. (When they are pushed in, their hooks open and they are locked automatically.) Then confirm that they are locked by pulling lightly on the lead wires.

Detaching

To detach a socket from a connector, pull out the lead wire while pressing the socket's hook with a stick having a thin tip (approx. 1 mm). If the socket will be used again, first spread the hook outward.




Replacement of Pilot Valve

ACaution

1.When replacing an old type VQZ valve with a new type for maintenance or other reasons, a "conversion connector assembly" is necessary to convert the connector from 3 terminals to 2 terminals and must be ordered separately. (When ordering, refer to the part no. below.)

For pilot valves, there is no compatibility between the old type and new type. When replacing a pilot valve, be sure to confirm whether it is the new type or the old type beforehand.







Be sure to read this before handling.

For Safety Instructions and 3 Port Solenoid Valve Precautions, refer to "Precautions for Handling Pneumatic Devices" (M-03-E3A).

How to Use DIN Terminal

1. EN-175301-803C (Previous DIN 43650C)

The DIN terminal type with an IP65 enclosure is protected against dust and water, however, it must not be used in water.

2. Connection

- 1) Loosen the holding screw and pull the connector out of the solenoid valve terminal block.
- After removing the holding screw, insert a flat head screwdriver, etc. into the notch on the bottom of the terminal block and pry it open, separating the terminal block and the housing.
- 3) Loosen the terminal screws (slotted screws) on the terminal block, insert the cores of the lead wires into the terminals according to the connection method, and fasten them securely with the terminal screws.
- 4) Secure the cord by fastening the ground nut.

3. Changing the entry direction

After separating the terminal block and housing, the cord entry can be changed by attaching the housing in the desired direction (4 directions at 90° intervals).

* When equipped with a light, be careful not to damage the light with the cord's lead wires.


4. Precautions

Plug in and pull out the connector vertically without tilting to one side.

5. Compatible cable

Cable O.D.: ø3.5 to ø7

(Reference) 0.5 mm², 2-core or 3-core, equivalent to JIS C 3306



DIN Connector Part No.


Without light

Rated voltage	Voltage symbol	Part no.		
All voltages	None	SY100-82-1		

With light

with light								
Rated voltage	Voltage symbol	Part no.						
24 VDC	24 V	SY100-82-3-05						
12 VDC	12 V	SY100-82-3-06						
100 VAC	100 V	SY100-82-2-01						
200 VAC	200 V	SY100-82-2-02						
110 VAC (115 VAC)	110 V	SY100-82-2-03						
220 VAC (230 VAC)	220 V	SY100-82-2-04						

Circuit diagram with light




One-touch fitting and Silencer Part No. for P, R Ports When Using Valve as an Individual Unit

Part no. for one-touch fitting for 1 (P) port and silencer for 3 (R) port

Series	(1) One-touch	(2) Sil	encer for 3(R)
Series	fitting for 1(P) port	Silencer	One-touch fitting
VQZ100	KQ2H06-M5	AN120-M5	KJS04-M5
VQZ200	KQ2S06-01S	INA-25-46	IN-457-32 (For ø6)
VQZ300	KQ2H08-02S	AN101-01	KQ2H06-01S

The diameter of the above fittings and silencers are the maximum diameters to lift in the EXH port.





Be sure to read this before handling.


For Safety Instructions and 3 Port Solenoid Valve Precautions, refer to "Precautions for Handling Pneumatic Devices" (M-03-E3A).

Changing the One-touch Fittings


ACaution

The built-in fittings on the manifold can be changed easily. Simply remove the corresponding valve and take out the fitting clip underneath.

Take out the clip with a screwdriver, etc., then replace the fittings. For mounting the fittings, insert the fitting until it stops, then put the clip into the prescribed position.



VQZ200: Clipped parallel to the valve body VQZ100/300: Clipped perpendicular to the valve body



Precautions

When pulling the fitting assembly away from the valve base, remove the clip, then connect a tube or plug (KQ2P- $\Box\Box$) with the one-touch fitting and pull it out holding the tube or plug. Do not hold the release bushing to avoid damage.

DIN Rail Removal/Mounting


ACaution

1. Removing

- Loosen the clamp screw on the (a) side of both ends of the manifold.
- Lift the ⓐ side ➡ of the manifold off the DIN rail and slide it in the direction of the ⓑ side.

2. Mounting


- 1) Catch the hook of the DIN rail bracket on the ⓑ side on the DIN rail.
- Push side (a) onto the DIN rail and tighten the clamp screw. The proper tightening torque for screws is 0.3 to 0.4 N•m.



Valve Mounting

ACaution

1. After confirming the gasket is correctly placed under the valve, securely tighten the bolts with the proper torque shown in the table below.




Change of Piping Direction

ACaution

1. How to replace the port direction

Fitting and port plug are modules. After removing the clip with a flat head screwdriver, take out the fitting and port plug. The piping direction (side or top) can be altered by exchanging the fitting and port plug. During exchange, insert the fitting and the port plug until they contact the wall, then, insert the clip to specified position.




Caution

The clip length for the valve and the base are different. Fitting may detach if the incorrect clip is used.

2.Valve piped on top can be operated independently by using PR plate.

(Refer to the below part numbers when placing an order.)



VQZ100-12A (standard spec.) VQZ100-12B (external pilot spec.) * 2 set screws are included.



EUROPEAN SUBSIDIARIES:

Austria

SMC Pneumatik GmbH (Austria). Girakstrasse 8 A-2100 Korneuburg

Phone: +43 2262-62280, Fax: +43 2262-62285 E-mail: office@smc.at http://www.smc.at



Belgium

SMC Pneumatics N.V./S.A. Nijverheidsstraat 20, B-2160 Wommelgem Phone: +32 (0)3-355-1464, Fax: +32 (0)3-355-1466 E-mail: post@smcpneumatics.be http://www.smcpneumatics.be



SMC Industrial Automation Bulgaria EOOD 16 kliment Ohridski Blvd., fl.13 BG-1756 Sofia Phone:+359 2 9744492, Fax:+359 2 9744519 E-mail: office@smc.bg http://www.smc.ba



Croatia SMC Industrijska automatika d.o.o. Crnomerec 12. 10000 ZAGREB Phone: +385 1 377 66 74, Fax: +385 1 377 66 74 E-mail: office@smc.hr http://www.smc.hr



Czech Republic

SMC Industrial Automation CZ s.r.o. Hudcova 78a, CZ-61200 Brno Phone: +420 5 414 24611, Fax: +420 5 412 18034 E-mail: office@smc.cz http://www.smc.cz



Denmark SMC Pneumatik A/S

Knudsminde 4B, DK-8300 Odder Phone: +45 70252900, Fax: +45 70252901 E-mail: smc@smc-pneumatik.dk http://www.smcdk.com



Estonia SMC Pneumatics Estonia OÜ Laki 12-101, 106 21 Tallinn Phone: +372 (0)6 593540, Fax: +372 (0)6 593541 E-mail: smc@smcpneumatics.ee http://www.smcpneumatics.ee



SMC Pneumatics Finland Oy PL72, Tiistinniityntie 4, SF-02031 ESPOO Phone: +358 207 513513, Fax: +358 207 513595 E-mail: smcfi@smc.fi http://www.smc.fi



OTHER SUBSIDIARIES WORLDWIDE:

ARGENTINA, AUSTRALIA, BOLIVIA, BRASIL, CANADA, CHILE, CHINA, HONG KONG, INDIA, INDONESIA, MALAYSIA, MEXICO, NEW ZEALAND, PHILIPPINES, SINGAPORE, SOUTH KOREA, TAIWAN, THAILAND, USA, VENEZUELA



SMC Pneumatique, S.A. 1, Boulevard de Strasbourg, Parc Gustave Eiffel Bussy Saint Georges F-77607 Mame La Vallee Cedex 3 Phone: +33 (0)1-6476 1000, Fax: +33 (0)1-6476 1010 E-mail: contact@smc-france.fr http://www.smc-france.fr



Germany

SMC Pneumatik GmbH Boschring 13-15, D-63329 Egelsbach Phone: +49 (0)6103-4020, Fax: +49 (0)6103-402139 E-mail: info@smc-pneumatik.de http://www.smc-pneumatik.de



SMC Hellas EPE Anagenniseos 7-9 - P.C. 14342. N. Philadelphia, Athens Phone: +30-210-2717265, Fax: +30-210-2717766 E-mail: sales@smchellas.gr http://www.smchellas.gr

Hungary

SMC Hungary Ipari Automatizálási Kft. Budafoki ut 107-113, H-1117 Budapest Phone: +36 1 371 1343, Fax: +36 1 371 1344 E-mail: office@smc.hu http://www.smc.hu

Ireland

Italy



SMC Pneumatics (Ireland) Ltd. 2002 Citywest Business Campus, Naas Road, Saggart, Co. Dublin Phone: +353 (0)1-403 9000, Fax: +353 (0)1-464-0500 E-mail: sales@smcpneumatics.ie http://www.smcpneumatics.ie



Via Garibaldi 62, I-20061Carugate, (Milano) Phone: +39 (0)2-92711, Fax: +39 (0)2-9271365 E-mail: mailbox@smcitalia.it http://www.smcitalia.it



Latvia SMC Pneumatics Latvia SIA Smerla 1-705, Riga LV-1006, Latvia Phone: +371 781-77-00, Fax: +371 781-77-01 E-mail: info@smclv.lv http://www.smclv.lv



Savanoriu pr. 180, LT-01354 Vilnius, Lithuania Phone: +370 5 264 81 26, Fax: +370 5 264 81 26

Netherlands

SMC Pneumatics BV De Ruyterkade 120, NL-1011 AB Amsterdam Phone: +31 (0)20-5318888, Fax: +31 (0)20-5318880 E-mail: info@smcpneumatics.nl http://www.smcpneumatics.nl



SMC Pneumatics Norway A/S Vollsveien 13 C, Granfos Næringspark N-1366 Lysaker Tel: +47 67 12 90 20, Fax: +47 67 12 90 21 E-mail: post@smc-norge.no http://www.smc-norge.no



SMC Industrial Automation Polska Sp.z.o.o. ul. Konstruktorska 11A, PL-02-673 Warszawa, Phone: +48 22 548 5085, Fax: +48 22 548 5087 E-mail: office@smc.pl http://www.smc.pl



SMC Sucursal Portugal, S.A. Rua de Eng^o Ferreira Dias 452, 4100-246 Porto Phone: +351 22-610-89-22, Fax: +351 22-610-89-36 E-mail: postpt@smc.smces.es http://www.smces.es

Romania

SMC Romania srl Str Frunzei 29, Sector 2, Bucharest Phone: +40 213205111, Fax: +40 213261489 E-mail: smcromania@smcromania.ro http://www.smcromania.ro



SMC Pneumatik LLC. 4B Sverdlovskaja nab, St. Petersburg 195009 Phone.:+812 718 5445, Fax:+812 718 5449 E-mail: info@smc-pneumatik.ru http://www.smc-pneumatik.ru



Slovakia SMC Priemyselná Automatizáciá, s.r.o. Námestie Martina Benku 10, SK-81107 Bratislava Phone: +421 2 444 56725, Fax: +421 2 444 56028 Empilie difere @orcs z.F E-mail: office@smc.sk http://www.smc.sk



SMC industrijska Avtomatika d.o.o. Grajski trg 15, SLO-8360 Zuzemberk Phone: +386 738 85240 Fax: +386 738 85249



SMC España, S.A. Zuazobidea 14, 01015 Vitoria Phone: +34 945-184 100, Fax: +34 945-184 124 E-mail: post@smc.smces.es http://www.smces.es



Sweden SMC Pneumatics Sweden AB Ekhagsvägen 29-31, S-141 71 Huddinge Phone: +46 (0)8-603 12 00, Fax: +46 (0)8-603 12 90 E-mail: post@smcpneumatics.se http://www.smc.nu



SMC Pneumatik AG Dorfstrasse 7, CH-8484 Weisslingen Phone: +41 (0)52-396-3131, Fax: +41 (0)52-396-3191 E-mail: info@smc.ch http://www.smc.ch



Entek Pnömatik San. ve Tic Ltd. Sti. Perpa Tic. Merkezi Kat: 11 No: 1625, TR-80270 Okmeydani Istanbul Phone: +90 (0)212-221-1512, Fax: +90 (0)212-221-1519 E-mail: smc-entek@entek.com.tr http://www.entek.com.tr




SMC Preumatics (UK) Ltd Vincent Avenue, Crownhill, Milton Keynes, MK8 0AN Phone: +44 (0)800 1382930 Fax: +44 (0)1908-555064 E-mail: sales@smcpneumatics.co.uk http://www.smcpneumatics.co.uk





Slovenia E-mail: office@smc.si http://www.smc.si

http://www.smceu.com http://www.smcworld.com





SMC Pneumatics Lietuva, UAB