



Clean Wet Series

High Purity Chemical Valve Compact Type

Space saving, compact type is available.

Compact type is introduced as a new series to complement conventional Series LVC with integral fittings. Select a series according to the flow rate and installation requirements. Mounting base dimensions conform to SEMI Standard, F65-1101. (Except for LVD10)

Body: **New PFA**
 Diaphragm: **PTFE**
 Actuator section: **PPS**



Series **LVD**


Integral fittings construction
 HYPER FITTING®
 Series LQ1 is used.

Integral clean one-touch fitting construction
 (Series KP is used.)
 Can select female thread (M5 x 0.8).


Integral tubing (construction)

Piping from 4 directions are possible.
 (Made to Order)

Dimension across inlet/outlet ports: Reduced by up to **29%**



	Class2		Class3		Class4		Class5	
	LVC20	LVD20	LVC30	LVD30	LVC40	LVD40	LVC50	LVD50
A	54.5	54.5	79	79.5	96	82	129	105.5
B	79	67	106	83	131	93	154	114



Diaphragm (PTFE)


Special diaphragm construction ensures gentle opening and closing that prevents the formation of micro-bubbles.

Minimal residual liquid

Residual liquid is minimized by the tapered shape and integral fitting construction, allowing liquid to flow smoothly, achieving improved swept flow characteristics.

Body (New PFA)

Compatible with chemicals such as acids, bases and ultra de-ionized water.



Guide ring

Eliminates lateral motion of the poppet which reduces internal leakage.

Piston damper

Absorbs piston momentum to minimize impact-induced particle generation.

Buffer

Protects diaphragm from deformation and damage due to back pressure.


Pilot port

Integral clean one-touch fittings construction. Can select female thread (M5).


Integral fittings construction

Offers quadruple seal construction. Nut lock mechanism. High flexural strength. Different tubing sizes can be selected.


Option



With flow rate adjustment



With by-pass



With flow rate adjustment & by-pass

Variations

Integral fittings

Orifice diameter	Flow characteristics $A_v \times 10^{-6} \text{ m}^2 \text{ (Cv)}$	Series	Applicable tubing size																					
			Metric size							Inch size														
			3	4	6	8	10	12	19	25	1/8	3/16	1/4	3/8	1/2	3/4	1							
2	2.1 (0.09)	LVD10	○														○							
4	8.4 (0.35)	LVD20		●													●	●	○					
8	31.2 (1.3)	LVD30			●	●		○											●	○				
10	45.6 (1.9)	LVD40						●	○											●	○			
16	120 (5)	LVD50							●	○											●	○		

● With reducer ○ Basic size

Integral tubing (construction)

Orifice diameter	Flow characteristics $A_v \times 10^{-6} \text{ m}^2 \text{ (Cv)}$	Series	Applicable tubing size											
			Metric size					Inch size						
			6	8	10	12	19	1/4	3/8	1/2	3/4			
4	8.4 (0.35)	LVD20	○							○				
8	31.2 (1.3)	LVD30			○							○		
10	45.6 (1.9)	LVD40				○							○	
16	120 (5)	LVD50					○							○

Integral Fitting Type (Hyper Fittings) Series *LVD*

How to Order

LVD 1 0 - S 03

Body class

Symbol	Body class	Orifice dia.
1	1	ø2
2	2	ø4
3	3	ø8
4	4	ø10
5	5	ø16

Valve type

0	N.C.
1	N.O.
2	Double acting

Note) Refer to "Variations" in the table below for valve type combinations.

Option

Nil	None
1	With flow rate adjustment
2	With by-pass
3	With flow rate adjustment & by-pass

Note) Refer to "Variations" in the table below for option combinations. Options can not be combined each other.

Material

Symbol	Body	Actuator section End plate	Diaphragm	Note
Nil	PFA	PPS	PTFE	—
N	PFA	PPS	PTFE	Ammonium hydroxide compatible

Applicable tubing size

Symbol	Connecting tubing outside diameter	Body class				
		1	2	3	4	5
Metric sizes						
03	ø3	○				
04	ø4	○	●			
06	ø6		○	●		
08	ø8			●		
10	ø10				○	●
12	ø12					○
19	ø19					○
Inch sizes						
03	1/8	○	●			
05	3/16		●			
07	1/4		○	●		
11	3/8			○	●	
13	1/2				○	●
19	3/4					○

○ Basic size ● With reducer









Pilot port thread type

Symbol	Body class	Thread type
Nil	1	ø4 one-touch fitting
	2, 3, 4, 5	ø6 one-touch fitting
2	1, 2, 3, 4, 5	M5


Port B (OUT) different dia. size

Symbol	Application
Nil	Ports A & B same size
Refer to the applicable tubing table to the left	Different diameter tubings can be selected within the same body class. Different diameter tubing can not be selected for the body size 1.

Variations

Type	Symbol	Model	Orifice diameter					
			LVD10	LVD20	LVD30	LVD40	LVD50	
			ø2	ø4	ø8	ø10	ø16	
Valve type	Symbol	Model	Tubing O.D.					
			Metric	Inch	Metric	Inch	Metric	Inch
Basic type			N.C.	○	○	○	○	○
			N.O.	○	○	○	○	○
			Double acting	○	○	○	○	○
With flow rate adjustment			N.C.	○	○	○	○	○
			Double acting	○	○	○	○	○
With by-pass			N.C.	—	○	○	○	○
			Double acting	—	○	○	○	○
With flow rate adjustment & by-pass			N.C.	—	○	○	○	○
			Double acting	—	○	○	○	○

Series LVD



Standard Specifications

Model		LVD10	LVD20	LVD30	LVD40	LVD50
Tubing O.D.	Metric	3, 4	4, 6	6, 8, 10	10, 12	12, 19
	Inch	1/8	1/8, 3/16, 1/4	1/4, 3/8	3/8, 1/2	1/2, 3/4
Orifice diameter		ø2	ø4	ø8	ø10	ø16
Flow characteristics	Av x 10 ⁻⁶ m ²	2.1	8.4	31.2	45.6	120
	Cv	0.09	0.35	1.3	1.9	5
Withstand pressure (MPa)		1				
Operating pressure (MPa) <A→B flow>		0 to 0.5		0 to 0.3		
Back pressure (MPa)		0.3 or less		0.2 or less		
Valve leakage (cm ³ /min)		0 (with water pressure)				
Pilot air pressure (MPa)		0.3 to 0.5				
Pilot port size	One-touch fitting	ø4 x ø3 tubing	ø6 x ø4 tubing			
	Threaded	M5				
Fluid temperature (°C)		0 to 100				
Ambient temperature (°C)		0 to 60				
Weight (kg)		0.04	0.09	0.16	0.19	0.40


Different Diameter Tubing Applicable with Reducer

Different diameter tubing can be selected (within a body class) by using a nut and insert bushing (reducer).

Different diameter tubing can not be selected for the body size 1.

● With reducer

Body class	Tubing O.D.												
	Metric sizes						Inch sizes						
	3	4	6	8	10	12	19	1/8	3/16	1/4	3/8	1/2	3/4
1	○	○	—	—	—	—	—	○	—	—	—	—	—
2	—	●	○	—	—	—	—	●	●	○	—	—	—
3	—	—	●	●	○	—	—	—	—	●	○	—	—
4	—	—	—	—	●	○	—	—	—	—	●	○	—
5	—	—	—	—	—	●	○	—	—	—	—	●	○

 Note) Refer to page 9 for information on changing tubing sizes.

⚠ Specific Product Precautions

Be sure to read before handling. Refer to pages 15 through 18 for safety instructions and high purity chemical valve precautions.

Piping

⚠ Caution

1. Connect tubing with special tools.

Refer to pages 9 through 11 regarding tubing connection and special tools.



2. Tighten the nut to the end surface of the body. As a guide, refer to the proper tightening torques shown below.

Tightening torque for piping

Body class	Torque (Nm)
2	0.3 to 0.4
3	0.8 to 1.0
4	1.0 to 1.2
5	2.5 to 3.0


Construction

**Standard type
N.C. type**




With reducer

With flow rate adjustment



With by-pass




Parts list

No.	Description	Material
1	Actuator section	PPS
2	Body	PFA
3	Diaphragm	PTFE
4	End plate	PPS
5	Insert bushing	PFA
6	Nut	PFA
7	Collar	PFA
8	Flow rate adjuster section	PPS



Series LVD

Dimensions

Basic type



Pilot port threaded type



Dimensions


(mm)

Model	A	B	C	D	E	F	G	H	J	K	L	M	N	P	Q	R	V
LVD1□-S□	20	20	45	39	9.5	46	23	11.5	4.5	11	30	5	21	ø4 (5/32")	28	22.5	M5
LVD2□-S□	30	30	54.4	56	11	67	28.5	13	4	20	44	7	23	ø6	31.5	17	M5
LVD3□-S□	35	35	79.5	62	17.5	83	45.5	14.5	6	22	50	7	37	ø6	36	21	M5
LVD4□-S□	35	35	82	62	20	93	48	14.5	6	22	50	7	39	ø6	36	21	M5
LVD5□-S□	45	45	105.5	76	25	114	65	17.5	8	32	64	7	52	ø6	38.5	25	M5

With flow rate adjustment

Dimensions (mm)


Model	S
LVD1□-S□	14
LVD2□-S□	11.5
LVD3□-S□	26
LVD4□-S□	26
LVD5□-S□	29.5



With by-pass

Dimensions (mm)


Model	T	U
LVD2□-S□	28	9.6
LVD3□-S□	34	17.5
LVD4□-S□	35	20
LVD5□-S□	57	25



With flow rate adjustment & by-pass

Dimensions (mm)

Model	S	T	U
LVD2□-S□	11.5	28	9.6
LVD3□-S□	26	34	17.5
LVD4□-S□	26	35	20
LVD5□-S□	29.5	57	25



Tube Extensions

Series *LVD*

How to Order

LVD 20 - T 06

Body class

Symbol	Body class	Orifice dia.
2	2	ø4
3	3	ø8
4	4	ø10
5	5	ø16

Valve type

0	N.C
1	N.O
2	Double acting

Note) Refer to "Variations" in the table below for valve type combinations.

Option

Nil	None
1	With flow rate adjustment

Note) Refer to "Variations" in the table below for option combinations.

Material

Symbol	Body	Actuator section	Diaphragm	Note
		End plate		
Nil	PFA	PPS	PTFE	—
N	PFA	PPS	PTFE	Ammonium hydroxide compatible





Pilot port thread type

Symbol	Body class
Nil	ø6 one-touch fitting
2	M5


Tubing O.D.

Symbol	Tubing O.D.	Body class			
		2	3	4	5
Metric sizes					
06	ø6	○			
10	ø10		○		
12	ø12			○	
19	ø19				○
Inch sizes					
07	1/4	○			
11	3/8		○		
13	1/2			○	
19	3/4				○

Variations

Type	Symbol	Model	Orifice diameter			
			Tubing O.D.			
			Valve type			
			Metric	Inch	Metric	Inch
		LVD20-T	LVD30-T	LVD40-T	LVD50-T	
		ø4	ø8	ø10	ø16	
		6	10	12	19	
		1/4	3/8	1/2	3/4	
Basic type 	 N.C. N.O. Double acting	N.C.	○	○	○	○
		N.O.	○	○	○	○
		Double acting	○	○	○	○
With flow rate adjustment 	 N.C. Double acting	N.C.	○	○	○	○
		Double acting	○	○	○	○

Standard Specifications




⚠ Specific Product Precautions

Be sure to read before handling. Refer to pages 15 through 18 for safety instructions and high purity chemical valve precautions.


Model		LVD20	LVD30	LVD40	LVD50
Tubing O.D.	Metric	6	10	12	19
	Inch	1/4	3/8	1/2	3/4
Orifice diameter		ø4	ø8	ø10	ø16
Flow characteristics	$Av \times 10^{-6} m^2$	8.4	31.2	45.6	120
	Cv	0.35	1.3	1.9	5
Withstand pressure (MPa)		1			
Operating pressure (MPa) <A→B flow>		0 to 0.5	0 to 0.3		
Back pressure (MPa)		0.3 or less	0.2 or less		
Valve leakage (cm ³ /min)		0 (with water pressure)			
Pilot air pressure (MPa)		0.3 to 0.5			
Pilot port size	One-touch fitting	ø6 x ø4 tube			
	Threaded	M5			
Fluid temperature (°C)		0 to 100			
Ambient temperature (°C)		0 to 60			
Weight (kg)		0.09	0.15	0.17	0.36

Construction


Standard type
N.C. type




N.O. type



Double acting type



With flow rate adjustment




Parts list

No.	Description	Material
1	Actuator section	PPS
2	Body	PFA
3	Diaphragm	PTFE
4	End plate	PPS
5	Flow rate adjuster section	PPS



Series LVD

Dimensions


Basic type



Pilot port threaded type



With flow rate adjustment



Dimensions (mm)

Model	S
LVD2□-T□	13
LVD3□-T□	26
LVD4□-T□	26
LVD5□-T□	29.5

Dimensions

Model	A	B	C	D	E	F	G	H	J	K	L	M	N	P	Q	T	U
LVD2□-T□	30	30	61	56	14.5	104	35	13	4	20	44	7	30	ø6	31.5	17	M5
LVD3□-T□	35	35	79.5	62	17.5	136	42.5	17.5	6	22	50	7	37	ø6	36	21	M5
LVD4□-T□	35	35	82	62	20	137	45	17.5	6	22	50	7	39	ø6	36	21	M5
LVD5□-T□	45	45	105.5	76	25	169.5	65	17.5	8	32	64	7	52	ø6	38.5	25	M5

Series LVD

Fittings and Special Tools

Fittings

Changing tubing sizes

The tubing size can be changed within the same body class (body size) by replacing the nut and insert bushing.

Body class	Tubing O.D.												
	Metric sizes						Inch sizes						
	3	4	6	8	10	12	19	1/8	3/16	1/4	3/8	1/2	3/4
1	○	○	—	—	—	—	—	○	—	—	—	—	—
2	—	●	○	—	—	—	—	●	●	○	—	—	—
3	—	—	●	●	○	—	—	—	—	●	○	—	—
4	—	—	—	—	●	○	—	—	—	—	●	○	—
5	—	—	—	—	—	●	○	—	—	—	—	●	○

Part composition


	Component parts		
	Nut	Insert	Collar (Insert assembly)
○ Basic size	Yes	Yes	No
● Reducer type	Yes	Yes	Yes

Changing the tubing size

Example) Changing the tubing from an outside diameter of 1/4" to 1/8" in body class 2.

Prepare an insert bushing and nut for 1/8" O.D. tubing (LQ-2U03) and change the tubing size.
(Refer to the section on how to order fitting parts.)

Note) Tubing is sold separately.



How to order fitting parts

LQ1-1U03

* Type U is recommended when changing tubing sizes.

Body class	
Symbol	Body class
1	1
2	2
3	3
4	4
5	5

Type of part	
Symbol	Type of part
U	Nut & Insert bushing
B	Insert bushing
N	Nut

Tubing size

Symbol	Tubing O.D.	Body class
03	1/8", ø3	1
04	ø4	
03	1/8"	2
04	ø4	
05	3/16"	3
06	ø6	
07	1/4"	4
08	ø8	
10	ø10	5
07	1/4"	
11	3/8"	4
10	ø10	
12	ø12	5
11	3/8"	
13	1/2"	5
12	ø12	
13	1/2"	5
19	3/4", ø19	

Special Tools

How to order fitting jigs

LQ-G J [] - [] - []

Insert pin material

Nil	Resin
S	Stainless steel (J/K type only)

Insert pin/Holder type


Nil	Metric size
N	Inch size







Note 1) Compatible pins and holders are included with all sizes. (with the parts case)

Option (L/M type only)

Symbol	Option
Nil	None
B	With bracket



Type

Symbol	Body class	J type	K type
J, K	1, 2		
L, M	1, 2, 3, 4, 5, 6		

Option


	Description	Part No.
Bracket assembly		LQ-GBL

Table 1 Tubing size symbols

Type	Body class	Tubing O.D.															
		Metric sizes								Inch sizes							
		ø3	ø4	ø6	ø8	ø10	ø12	ø19	ø25	1/8"	3/16"	1/4"	3/8"	1/2"	3/4"	1"	
J	1	03	04	—	—	—	—	—	03	—	—	—	—	—	—		
	2	—	04	06	—	—	—	—	03	05	07	—	—	—	—		
L	1	03	04	—	—	—	—	—	03	—	—	—	—	—	—		
	2	—	04	06	—	—	—	—	03	05	07	—	—	—	—		
	3	—	—	06	08	10	—	—	—	—	07	11	—	—	—		
	4	—	—	—	—	10	12	—	—	—	—	11	13	—	—		
	5	—	—	—	—	—	12	19	—	—	—	—	13	19	—		
	6	—	—	—	—	—	—	19	25	—	—	—	—	19	25		

Replacement parts

Description	Part No.								
Insert pin holder assembly (with the parts case)	<p>LQ-GP J [] - []</p> <p>Type ↓</p> <p>Insert pin/Holder type</p> <table border="1"> <tr> <td>Nil</td> <td>Metric size</td> </tr> <tr> <td>N</td> <td>Inch size</td> </tr> </table> <p>Insert pin material (J/K type only)</p> <table border="1"> <tr> <td>Nil</td> <td>Resin</td> </tr> <tr> <td>S</td> <td>Stainless steel</td> </tr> </table>	Nil	Metric size	N	Inch size	Nil	Resin	S	Stainless steel
Nil	Metric size								
N	Inch size								
Nil	Resin								
S	Stainless steel								
Insert pin (Single)	<p>LQ-GP [2] J [] - [07]</p> <p>Body class (Refer to Table 1) ↓</p> <p>Type ↓</p> <p>Insert pin material (J/K type only)</p> <table border="1"> <tr> <td>Nil</td> <td>Resin</td> </tr> <tr> <td>S</td> <td>Stainless steel</td> </tr> </table> <p>Tubing size symbol (Refer to Table 1) ↓</p>	Nil	Resin	S	Stainless steel				
Nil	Resin								
S	Stainless steel								
Holder (Single)	<p>LQ-GH J [] - [07]</p> <p>Type ↓</p> <p>Tubing size symbol (Refer to Table 1) ↓</p>								




Note1) Replacement part type J shows the parts for LQ-GJ and LQ-GK. Replacement part type L shows the parts for LQ-GL and LQ-GM.


Special Tools

Dimensions


LQ-GJ




LQ-GK



LQ-GM




LQ-GL




Fitting Assembly Procedure

Assemble fittings following the procedure shown below.

J type



K type



J type fitting assembly procedure

- 1 Pull out the lever pin ①. Rotate the lever assembly ② to align the holes on the lever assembly ② and the base ③. Insert the lever pin ① into the holes to fix the lever assembly ②.
 - 2 Place the insert bushing ⑤ on the insert pin assembly ④.
 - 3 Cut the end of the tubing ⑥ at a right angle and pass it through the fitting nut ⑦. After placing the tubing ⑥ in the holder assembly ⑧, push it onto the insert bushing ⑤ until it stops and clamp it with the hook ⑨.
- ⚠ Caution**
- When the tubing ⑥ is curved, straighten it out before using it.
 - The tubing ⑥ may slip if there is oil or dust, etc., on the holder assembly ⑧. Remove the contamination using alcohol or another suitable cleaner.
- 4 Press the insert bushing ⑤ into the tubing ⑥ by turning the lever assembly ②.
 - 5 To replace the insert pin assembly ④ and holder assembly ⑧, use the insert pin assembly replacement screw ⑩ and the holder assembly replacement screws ⑪, respectively.

K type fitting assembly procedure


- For procedure to set and press fit the insert pin assembly, refer to L, M type fitting assembly procedures.
- For procedure to set the tubing, refer to J type procedure.

- 1 } Refer to J type assembly procedure.
- 5 }
- 6 Tighten the fitting nut ⑦ until it reaches the prescribed position on the body (end face). As a guide, refer to the proper tightening torques shown below.

Nut tightening torque for piping

Body class	Torque (Nm)	
	LQ1	LQ2
2	0.3 to 0.4	1.5 to 2.0


Note 1) In case of body class 1, the nut should be tightened manually.





Fitting Assembly Procedure

Assemble fittings following the procedure shown below.

L type



M type




L/M type fitting assembly procedure

- 1 Turn the **lever** ① and move to SET POS.
- 2 Place the **insert bushing** ③ on the **insert pin assembly** ②.
- 3 Cut the end of the **tubing** ④ at a right angle and pass it through the **fitting nut** ⑤.
After placing the **tubing** ④ in the **holder assembly** ⑥, push it onto the **insert bushing** ③ until it stops and clamp it with the **knob** ⑦.
As a guide when tightening the **tubing** ④ with the **knob** ⑦, maintain a uniform gap on both sides of the holder.
- ⚠ Caution**
 - When the **tubing** ④ is curved, straighten it out before using it.
 - The **tubing** ④ may slip if there is oil or dust, etc. on the **holder assembly** ⑥. Remove the contamination using alcohol or another suitable cleaner.
- 4 Press the **insert bushing** ③ into the **tubing** ④ by turning the **lever** ①. (Pressing in can be accomplished with 2 or 3 turns of the **lever** ①.)
- 5 To replace the **insert pin assembly** ② and **holder assembly** ⑥, use the **insert pin assembly replacement screw** ⑨ and the **holder assembly replacement screws** ⑩, respectively.
- 6 In case of M type for short piping, remove the **handle** ⑪, slide the **clamp assembly** ⑫ to attain the specified length, then secure it again with the **handle** ⑪.
- 7 Tighten the **fitting nut** ⑤ to the prescribed position on the body (end face).
As a guide, refer to the proper tightening torques shown below.

Nut tightening torque for piping

Body class	Torque (Nm)	
	LQ1	LQ2
2	0.3 to 0.4	1.5 to 2.0
3	0.8 to 1.0	3.0 to 3.5
4	1.0 to 1.2	7.5 to 9
5	2.5 to 3.0	11 to 13
6	5.5 to 6.0	—

 Note 1) In case of body class 1, the nut should be tightened manually.

⚠ Precautions on installation

- Be careful not to scratch or dent the seal of the insert bushing. (Refer to the illustration on the left.)
- When the insert bushing inserted, its tubing end should be closer to seal side than the minimum position. (Refer to the illustration on the left.)



Applicable Fluids

Material and fluid compatibility check list for High Purity Chemical Valves

Chemical	Compatibility
Acetone	<input type="radio"/> Note 1, 2)
Ammonium hydroxide	<input type="radio"/> Note 2)
Isobutyl alcohol	<input type="radio"/> Note 1, 2)
Isopropyl alcohol	<input type="radio"/> Note 1, 2)
Hydrochloric acid	<input type="radio"/>
Ozone (dry)	<input type="radio"/>
Hydrogen peroxide Concentration 5% or less, 50°C or less	<input type="radio"/>
Ethyl acetate	<input type="radio"/> Note 1, 2)
Butyl acetate	<input type="radio"/> Note 1, 2)
Nitric acid (except fuming nitric acid) Concentration 10% or less	<input type="radio"/> Note 2)
DI water	<input type="radio"/>
Sodium hydroxide Concentration 50% or less	<input type="radio"/>
Nitrogen gas	<input type="radio"/>
Super pure water	<input type="radio"/>
Toluene	<input type="radio"/> Note 1, 2)
Hydrofluoric acid	×
Sulfuric acid (except fuming sulfuric acid)	<input type="radio"/> Note 2)
Phosphoric acid Concentration 80% or less	<input type="radio"/>

Table symbols : Can be used
 : Can be used in certain conditions
× : Cannot be used



The material and fluid compatibility check list provides reference values as a guide only.

Note 1) Since static electricity may be generated, implement suitable countermeasures.

Note 2) Use caution as permeation may occur. The permeated fluid may effect the parts of other materials.


- Compatibility is indicated for fluid temperatures of 100°C or less.
- The material and fluid compatibility check list provides reference values as a guide only, therefore we do not guarantee the application to our product.
- The data above is based on the information presented by the material manufacturers.
- SMC is not responsible for its accuracy and any damage happened because of this data.





Series LVD

Safety Instructions

These safety instructions are intended to prevent a hazardous situation and/or equipment damage. These instructions indicate the level of potential hazard by labels of "**Caution**", "**Warning**" or "**Danger**". To ensure safety, be sure to observe ISO 4414 ^{Note 1)}, JIS B 8370 ^{Note 2)} and other safety practices.

 **Caution** : Operator error could result in injury or equipment damage.

 **Warning** : Operator error could result in serious injury or loss of life.

 **Danger** : In extreme conditions, there is a possible result of serious injury or loss of life.

Note 1) ISO 4414: Pneumatic fluid power --General rules relating to systems

Note 2) JIS B 8370 : Pneumatic system axiom.

Warning

1. The compatibility of equipment is the responsibility of the person who designs the system or decides its specifications.

Since the products specified here are used in various operating conditions, their compatibility for the specific system must be based on specifications or after analysis and/or tests to meet your specific requirements. The expected performance and safety assurance will be the responsibility of the person who has determined the compatibility of the system. This person should continuously review the suitability of all items specified. Referring to the latest catalogue information with a view to giving due consideration to any possibility of equipment failure when configuring a system.

2. Only trained personnel should operate machinery and equipment.

Assembly, handling or maintenance of machinery and equipment should be performed by trained and experienced operators.

3. Do not service machinery/equipment or attempt to remove components until safety is confirmed.

4. To promote safe operation, be sure to observe company standards and legal regulations, etc.

Refer to ISO4414, JIS B 8370 (pneumatic system axiom), labour health and safety laws and other safety regulations.



Series LVD

High Purity Chemical Valve, Compact Type Precautions 1

Be sure to read before handling.

Design & Selection

Warning

1. Confirm the specifications.

Give careful consideration to operating conditions such as the application, fluid and environment, and use within the operating ranges specified in this catalogue.

2. Fluids

Operate after confirming the compatibility of the product's component materials with fluids, using the check list on page 14. Contact SMC regarding fluids other than those in the check list.

Operate within the indicated fluid temperature range.

3. Maintenance space

Ensure the necessary space for maintenance and inspections.

4. Fluid pressure range

Keep the supplied fluid pressure within the operating pressure range shown in the catalog.

5. Ambient environment

Operate within the ambient operating temperature range. After confirming the compatibility of the product's component materials with the ambient environment, operate so that fluid does not adhere to the product's exterior surfaces.

6. Liquid seals

When circulating fluid

Provide a relief valve in the system so that fluid does not get into the liquid seal circuit.

7. Countermeasures for static electricity

Since static electricity may be generated depending on the fluid being used, implement suitable countermeasures.

Mounting

Warning

1. If air leakage increases or equipment does not operate properly, stop operation.

After mounting, perform suitable function and leak tests to confirm that the mounting is correct.

2. Instruction manual

Mount and operate the product after reading the manual carefully and understanding its contents. Also keep the manual where it can be referred to as necessary.

Piping

Caution

1. Preparation before piping

Before piping is connected, it should be thoroughly blown out with air (flushing) or washed to remove chips, cutting oil and other debris from inside the pipe.

Install piping so that it does not apply pulling, pressing, bending or other forces on the valve body.

2. Use the tightening torques shown below for the threaded pilot port.

Operating port tightening torque

Operating port	Torque (Nm)
M5	1/6 turn with a tightening tool after first tightening by hand

3. Use pilot ports and sensor (breathing) ports as indicated below.

	PA Port	PB Port	Sensor (breathing) port
N.C.	Pressure	Breathing	Breathing
N.O.	Breathing	Pressure	Breathing
Double acting	Pressure	Pressure	Breathing

In the case of N.C. and N.O. types, the port which does not receive operating pressure is released to atmosphere. When intake and exhaust directly from the valve is not desired due to problems with the ambient environment or scattering of dust, etc., install piping and perform intake and exhaust at a location which does not present a problem.

4. See page 12 regarding tubing connections.

Operating Air Supply

Warning

1. Use clean air.

Do not use compressed air which includes chemicals, synthetic oils containing organic solvents, salt, or corrosive gases, etc., as this may cause damage or malfunction.



Series LVD

High Purity Chemical Valve, Compact Type Precautions 2

Be sure to read before handling.

Installation and Removal of Tubing for Pilot Port Section

Caution

1. Installation of tubing

- 1) Using tube cutters TK-1, 2 or 3, take a tube having no flaws on its periphery and cut it off at a right angle. Do not use pinchers, nippers or scissors, etc. The tubing might be cut diagonally or flattened, making installation impossible or causing problems such as disconnection and leakage.
- 2) Hold the tube and push it in slowly, inserting it securely all the way into the fitting.
- 3) After inserting the tubing, pull on it tightly to confirm that it will not come out. If it is not installed securely all the way into the fitting, problems such as leakage or disconnection of the tubing can occur.
- 4) Grease is not used due to the series KP oil-free specifications. For this reason, greater insertion force is required when tubing is installed. In particular, polyurethane tubing may fold when inserted due to its softness. Hold the end of the tubing, and insert it all the way in slowly and securely. Refer to dimension "M" in the dimension drawings for guidance on the insertion depth of tubing.

2. Removal of tubing

- 1) Push in the release button sufficiently, pressing the collar evenly around its circumference.
- 2) Pull out the tubing while holding down the release button so that it does not pop out. If the release button is not pressed down sufficiently, there will be increased bite on the tubing and it will become more difficult to pull it out.
- 3) When the removed tubing is to be used again, first cut off the section of the tubing which has been chewed. Using the chewed portion of the tube as it is can cause problems such as leakage or difficulty in removing the tubing.

Precautions on Use of Other Tubing Brands

Caution

1. When using tubing brands other than SMC, confirm that the tubing outside diameter tolerances satisfy the following specifications.

- | | |
|------------------------|---------------------|
| 1) Polyolefin tubing | ±0.1 mm |
| 2) Polyurethane tubing | +0.15 mm
-0.2 mm |
| 3) Nylon tubing | ±0.1 mm |
| 4) Soft nylon tubing | ±0.1 mm |

Do not use tubing if the outside diameter tolerance is not satisfied. It may not be possible to connect the tubing, or leakage or disconnection may occur after connection.

Polyolefin tubing is recommended for use with clean room fittings. Note that while other types of tubing will satisfy performance standards for leakage and tubing pull-out strength, etc., the degree of cleanliness will deteriorate.

Operating Environment

Warning

1. Do not use in a location having an explosive atmosphere.
2. Do not operate in locations where vibration or impact occurs.
3. Do not use in locations where radiated heat will be received from nearby heat sources.

Maintenance

Warning

1. Maintenance should be performed in accordance with the procedures in the instruction manual.

Incorrect handling can cause damage or malfunction of machinery and equipment, etc.

2. Before removing equipment or compressed air supply/exhaust devices, shut off the air and power supplies, and exhaust compressed air from the system.

Further, when restarting equipment after re-mounting or replacement, first confirm safety and then check the equipment for normal operation.

3. Perform work after removing residual chemicals and carefully replacing them with DI water or air, etc.
4. Do not disassemble the product. Products which have been disassembled cannot be guaranteed.

If disassembly is necessary, contact SMC.

5. In order to obtain optimum performance from valves, perform periodic inspections to confirm that there are no leaks from valves or fittings, etc.

Caution

1. Removal of drainage

Flush drainage from filters regularly.



Series LVD

High Purity Chemical Valve, Compact Type Precautions 3

Be sure to read before handling.

Precautions on Usage

⚠ Warning

1. Operate within the ranges of the maximum operating pressure and back pressure.

⚠ Caution

1. Please note that when the product is shipped from the factory, gases such as N₂ and air may leak from the valve at a rate of 1 cm³/min (when pressurized).
2. When operated at a very low flow rate, the series LVD with flow rate adjustment may vibrate, etc. depending on the operating conditions. Therefore, operate it after careful examination of the flow rate, pressure and piping conditions.
3. In the series LVD, water hammering may occur depending on the fluid pressure conditions. In most cases, improvement is possible by adjusting the pilot pressure with a speed controller, etc., but the flow rate, pressure and piping conditions should be reviewed.

⚠ Caution

4. To adjust the flow rate for the series LVD with flow rate adjustment, open gradually starting from the fully closed condition. Opening is accomplished by turning the adjustment knob counter clockwise. Additionally, do not apply any unreasonable force to the adjustment handle when nearing a fully opened or closed state. This may result in deformation of the orifice sheet surface or damage to the threaded part of the adjustment handle. It is in the fully closed condition when the product is shipped from the factory.
5. After a long period of nonuse, perform a test run before beginning regular operation.
6. Since the LVD is packaged in a clean room use sufficient care in handling when opened.
7. In the case of the integral tubing type, be certain that the fittings are not applicable by heating up the tubing with a heat gun, for example.

SMC CORPORATION (Europe)

Austria	☎ +43 226262280	www.smc.at	sales@smc.at	Netherlands	☎ +31 205318888	www.smc-pneumatics.nl	info@smc-pneumatics.nl
Belgium	☎ +32 33551464	www.smc-pneumatics.be	post@smc-pneumatics.be	Norway	☎ +47 67129020	www.smc-norge.no	post@smc-norge.no
Bulgaria	☎ +359 2 9744492	www.smc.bg	sales@smc.at	Poland	☎ +48 225485085	www.smc.pl	office@smc.pl
Czech Republic	☎ +42 0541424611	www.smc.cz	office@smc.cz	Portugal	☎ +351 226108922	www.smces.es	postpt@smc.smces.es
Denmark	☎ +45 70252900	www.smc-pneumatik.dk	smc@smc-pneumatik.dk	Romania	☎ +40 213205111	www.smcromania.ro	smcromania@smcromania.ro
Estonia	☎ +372 6593540	www.smc-pneumatics.ee	smc@smc-pneumatics.ee	Russia	☎ +812 1185445	www.smc-pneumatik.ru	smcfa@peterlink.ru
Finland	☎ +358 9859580	www.smc.fi	smc@smc-pneumatik.de	Slovakia	☎ +421 244456725	www.smc.sk	office@smc.sk
France	☎ +33 164761000	www.smc-france.fr	contact@smc-france.fr	Slovenia	☎ +386(7)3885249	www.smc-ind-avtom.si	office@smc-ind-avtom.si
Germany	☎ +49 61034020	www.smc-pneumatik.de	info@smc-pneumatik.de	Spain	☎ +34 945184100	www.smces.es	post@smc.smces.es
Greece	☎ +30 2103426076	www.smceu.com	parianos@hol.gr	Sweden	☎ +46 86030700	www.smc.nu	post@smc-pneumatics.se
Hungary	☎ +36 13711343	www.smc-automation.hu	office@smc-automation.hu	Switzerland	☎ +41 523963131	www.smc.ch	info@smc.ch
Ireland	☎ +353 14039000	www.smc-pneumatics.ie	sales@smc-pneumatics.ie	Turkey	☎ +90 2122211516	www.entek.com.tr	smc-entek@entek.com.tr
Italy	☎ +39 0292711	www.smcitalia.it	mailbox@smcitalia.it	UK	☎ +44 8001382930	www.smc-pneumatics.co.uk	sales@smc-pneumatics.co.uk
Latvia	☎ +37 7779474	www.smclv.lv	info@smclv.lv				

European Marketing Centre ☎ +34 945184100
SMC CORPORATION ☎ +81 0335022740

www.smceu.com
www.smcworld.com